




sunhydraulics.com/model/991284


The twist/lock manual override is a rotary, hand-actuated device for use on Sun's (full flow solenoid valves and FLeX series valves). The hand knob is constructed of a reinforced plastic for durability, heat resistance, and stability in varying environmental conditions and is suitable for operation with a gloved hand. The override assembly incorporates a sealed-construction design thereby preventing the introduction of debris and other damaging contamination. Once installed on a Sun solenoid valve, the override feature allows the operator to manually shift the de-energized valve. Solenoid cartridges may be ordered in this configuration by specifying a "L" control in the cartridge model number. Sun kits for field conversion are also available. Please note that valves with the twist/lock manual override are not suitable for load holding applications.

TECHNISCHE DATEN

Für Einschraubventile	DBAF, DFBD, DFBE, DFBF, DFBG, DLDF, DTAF, DTBF, DWBD, DWBF, DWDF
Werkstoff	Schwarzer Kunststoff und Aluminium
Beschreibung	L-Verstellung (Drehbare Handbetätigung, rastbar)
Betriebsdrehmoment	15 lbf in.

INFO

- 1. Prüfen Sie, ob der O-Ring an der Unterseite der Handbetätigung vorhanden ist.
- 2. Entfernen Sie die Befestigungsmutter der Spule vom Ende des Ankerrohres.
- 3. Schrauben Sie die Handbetätigung auf das Ende des Ankerrohres. Richten Sie den Spulenstecker aus, bevor Sie die Handbetätigung handfest anziehen.
- Hinweis: Bei ungünstigen Bedingungen ist eine Gewindesicherung zu empfehlen.

USED WITH

DBAF DFBD DFBE DFBF DFBG DLDF DTAF DTBF DTDF DWDF